# **Configure Roads & Highways Interface**

To configure the R & H interface to work with other systems, follow the steps below:

- Configure the Interface on the AgileAssets System
- Configure LRMs on the AgileAssets System
- Make a Connection between ArcCatalog and the AgileAssets System
- Register External Events with Roads and Highways
- Register the Roads & Highways database with ArcGIS Server
- Create Roads and Highways Export Network Web Service
- Create Roads and Highways Relocate Events Web Services
- Create LastEditDate Web Service
  - Command Line Option:
  - ArcMap Option:
- Complete Interface Configuration on the AgileAssets System
- Install native FGDB libraries
- Make at least one event table temporal
- Configure Excluded Tables and Interface Type

### Configure the Interface on the AgileAssets System

On standard systems, the configuration page for this interface is accessed by following the steps below:

- 1. Click LRS/GIS in the top ribbon
- 2. Select Roads & Highways Interface
- 3. Select LRS Interface Setup



System - Utilities - Setup - FL	DC - Tools - Network - R	eports - LRS/GIS -				*• *·	- 🥝 💄 PHILH -
System > LRS/GIS > Roads & Highways	s Interface > LRS Interface Setu	p ☆					Save 2 Reload
Export Network Setup Actions V							iii 26
Export Network URL	Time Zone	System ID	SRID	Execution Wait (s)	Execution Timeout (s)	Download Timeout (s)	LastEditDate service link
•	US/Mountain -	AgileAssets Asset Managı 👻	26913	5	7200	1200	
<< < 1 of 1 total rows> >>							
Relocate Events Setup - Event Categori	ies Actions ¥						i≣ 23
Base Events Table Name   Relocate Ev	ents URL (Points)	Relocate Events URL	(Lines)	Default Event Table?	Execution Wait (s)	Execution Timeout (s)	Download Timeout (s)
AGILE_EVENTS						5 7200	1200
SPECIAL_EVENTS					6	5 7200	1200
<< < 2 of 2 total rows> >>							
Relocate Events Setup - Member Tables	S Actions ▼						⊞ 23
Source Table  PMS_TRAFFIC	*						
<< < <u>1</u> of 1 total rows> >>							?

The configuration page is divided into the following three panes:

- Export Network Setup: (top pane) configures the part of the interface that imports the LRS. Note that there is one and only one record for this pane. You can modify the following fields:
  - Export Network URL This is the URL of the Roads and Highways Export Network web service. This can be left blank at this point in the configuration
  - $^\circ~$  Time Zone Set this to match the time zone configured in the Roads and Highways instance
  - System ID Pick the system associated with the base LRM being updated by the interface
  - SRID This number indicates the map projection used for the Network in Roads & Highways a full list of these map projections is stored in the mdsys.cs\_srs table in Oracle
  - Execution Wait (s) The number of seconds the system waits before checking job status of the web service job again. The standard is 5 seconds
  - Execution Timeout (s) The number of seconds the system will wait from when the web service job is submitted until the job is finished. The standard is 7200 seconds (2 hours)
  - Download Timeout (s) The number of seconds the system waits for the download of the web service job results to complete. The standard is 1200 seconds (20 minutes)
  - LastEditDate service link This is the URL of the LastEditDate web service. This can be left blank at this point in the configuration because it is addressed in the Complete Interface Configuration on the AgileAssets System step.
- Relocate Events Setup Event Categories: (middle pane) configures different event categories and allows you to select which event tables belong to each category in the following pane. Categories can be configured for each different set of event behaviors that you want to employ for different event tables.

Note: To insert or delete a field in this pane, the database privileges assigned to the AgileAssets application must be set to allow the creation and deletion of tables.

The views created by this pane are the views that need to be registered with Roads and Highways and used in the creation of Relocate Events web services. You can insert records into this pane and modify the following fields:

- Base Events Table Name This is the base name of the two views created when a record is inserted in this pane. This base name will have "\_PTV" appended to it for point events and "\_LNV" appended to it for linear events.
- Relocate Events URL (Points) This is the URL of the Roads and Highways Relocate Events web service for the point events associated with this category. This can be left blank at this point in the configuration.
- Relocate Events URL (Lines) This is the URL of the Roads and Highways Relocate Events web service for the linear events associated with this category. This can be left blank at this point in the configuration because it is addressed in the <u>Complete Interface</u> <u>Configuration on the AgileAssets System</u>
- Default Event Table? By checking this option, it means that all event tables that are not specifically assigned to other categories will
  automatically be assigned to this category. There can be no more than one category with the default event table option checked. So,
  check this field if this is the default event category.
- Execution Wait (s) Then number of seconds the system waits before checking job status of the web service job again. The standard is 5 seconds.
- Execution Timeout (s) The number of seconds the system will wait from when the web service job is submitted until the job is finished. The standard is 7200 seconds (2 hours).
- **Download Timeout (s)** The number of seconds the system waits for the download of the web service job results to complete. The standard is 1200 seconds (20 minutes).
- Relocate Events Setup Member Tables: (bottom pane) configures which event tables are associated with each category in the Event Categories pane. The user first selects a category in the middle pane and then can enter the following field to be assigned to that category:
  - Source Table The user can insert from the pick list of event tables that they want associated with the selected event category. Each event table can be associated with at most one category. If the category chosen in the middle pane is the default category do not fill in any records in this field.

# Configure LRMs on the AgileAssets System

This step correlates the LRMs in the AgileAssets system with the Networks implemented in Esri Roads and Highways.

To configure this, navigate to the LRM Setup page by following the steps bellow:

- 1. Click LRS/GIS
- 2. Select Setup Location Reference Methods (LRMs)

For each LRM in the LRSs pane identify the number assigned to it on the Roads and Highways system in the dLRSNetworks domain and enter that number in the Net\_LRM\_ID field in the AgileAssets LRM Setup window. (Note: The Net\_LRM\_ID field may not be visible in the top pane. You must open design mode to add this field and then make it visible and editable.)

System >	LRS/GIS > Setup Lo	cation Refer	ence Methods (Lf	RMs) 🖒									🖺 Save	C Reload
LRSs Actions														H 25
Basic LRS?	* LOC REF NAME	^ Att.	Comments	User Updat	e Date Update									
•	Basic LRS													
<< < 1	of 1 total rows > >:	>												
Columns Acti	ns ¥													II 53
Column ID	Column Label	COLUMN	ID TO 0	COLUMN LABEL TO	* LRS column type	Initial Value	Show 'To'?	Order 🗅	NET ORDER ID	NET LOOKUP TABLE	NET LOOKUP ID COLUMN	NET LOOKUP NAME COLUMN		
ROUTE_ID	Route ID				Location Attribute		ø	1						
LANE_DIR	LRS Direction				Location Across	0	¥	4						
LANE_ID	Lane				Location Across	0	<b>v</b>	5						
PERPEN_OFFS8	T Offset				Location Across	0	<b>v</b>	6						
OFFSET_FROM	BMP	OFFSET_1	го е	EMP	Location Measure		1	7						
<< < 1	of 5 total rows > >:	>												

Also, in cases where an LRM has more than one route identification field (marked as Location Attribute in the bottom screen) you may need to assign each of these fields a value in the Net\_Order\_ID field. This specifies the preferred order of the route identification fields.

Note: The Net\_Order\_ID field may not be editable in the bottom pane. You may have to go into design mode to make it editable.

## Make a Connection between ArcCatalog and the AgileAssets System

In ArcCatalog, make a database connection to the Oracle instance underlying the AgileAssets implementation. The directions for creating an Oracle database connection can be found on the Esri website at http://desktop.arcgis.com/en/arcmap/latest/manage-data/gdbs-in-oracle/connect-oracle.htm.

Database Connection		<b>×</b>
Database Platform:	Oracle	•
Technologi	pailedbay 1521 / pailedba	
instance:	agileopp:1521/agileopp	1
Authentication Type:	Database authenticatio	n 🔻
	User name:	ams_WV_07_00_LRS
	Password:	•••••
	📝 Save user name and	l password
About Database Connections		OK Cancel

## Register External Events with Roads and Highways

For each record entered into the **Relocate Events Setup - Event Categories** pane of the LRS Interface Setup window on the AgileAssets system, you will have two External event views that must be registered to the Advanced Linear Referencing System (ALRS). The names of the External Event views are created from the Base Events Table Name field of each record plus "\_PTV" appended to it for point events and "\_LNV" appended to it for linear events.

The directions for registering External events to Roads and Highways can be found on the Esri website (http://desktop.arcgis.com/en/arcmap/latest /extensions/roads-and-highways/registering-an-external-event-source.htm). Make sure to complete the following:

- Register the "\_PTV" events as point events and the "\_LNV" events as linear events.
- These event views should be registered as External events.
- Point events only need the MEASURE field assigned to its single measure.

Catalog	ą	× \Lambda	<b>.</b>		ALRS Ev	en	at Setup
<ul> <li></li></ul>	ries	Edit Sketch Properties	G Se fie	eneral event prope elect general event pro elds Event feature class: Event location:	rties sperties, such as geometries, such as geometries EVENTS_TO_BE_ External event	UPI	y type and key
PS_ALRS     dats     dats	X Delete Rename C Refresh	Cre	-	Geometry type: Field mapping:	<ul> <li>Point event</li> <li>Line event</li> </ul>		
I RS Intersection (		<u> </u>		Field	Field Name		Required Field Type
Create a new	w file or new data in th	e		Event ID	EVENT_ID	~	Text(>=32)
H types listed	here depend on what			Route ID	ROUTE_ID	~	Text
Lrs your curren	t Catalog location is.			From Measure	FROM_MEASURE	~	Double
Lrs_Event_Beha	Properties	_		To Measure	TO_MEASURE	~	Double
Lrs_Locks				From Date	FROM_DATE	~	DateTime
LRSE_AADT				To Date	TO_DATE	~	DateTime
LRSE_AADT_20     LRSE_ACcess_C     LRSE_Attenuate     LRSE_Bridge_CI     LRSE_Bridge_Li     LRSE_Bridge_Po     LRSE_Bridge_Po	I5 ontrol er earance ne oint		_		[		<back next=""> Cancel</back>

Note: The external events need to be registered to the Network that is checked as the Basic LRS.

## Register the Roads & Highways database with ArcGIS Server

In almost all cases this step will have already been done, but it is listed here for completeness. However, the instructions for registration can be found on the Esri website (http://server.arcgis.com/en/server/latest/publish-services/windows/registering-your-data-with-arcgis-server-using-manager.htm).

## Create Roads and Highways Export Network Web Service

There are two main steps to creating the Export Network web service. First you must run the geoprocess, and then share the results of that geoprocess as a web service.

The directions for running the geoprocess and creating the web service can be found on the Esri website (http://desktop.arcgis.com/en/arcmap/latest /extensions/roads-and-highways-server/deploying-network-export-tool-as-a-service.htm).

- 1. In the Export Network dialog, select the base LRM of the AgileAssets system (as indicated by the Basic LRS check mark in Section 2.2).
- 2. When specifying the Output Export File make sure to include a full name with a directory path (e.g. C:\Temp\Export).
- 3. Select FGDB for output format.
- 4. Select the precision (number of digits to the right of the decimal point) that matches the precision of measures in the Setup\_Network\_Lines table in the AgileAssets system.
- 5. The LRM Translations value must be a comma-delimited list of the numbers that Roads and Highways assigns to the networks that correspond to any alternate LRMs in the AgileAssets system. These numbers are listed in the dLRSNetworks domain. And if there are no alternate LRMs that need to be handled via the Interface, then leave the LRM Translations field blank.
- 6. Leave the following fields blank: Last Invoked Time, LRS Time, Last LRS Time, and Output Spatial Reference WKID.

🔨 Export Network	- • •
Network Layer	<u> </u>
State_Milepoint	- 🖻
Output Export File	
c:\output	
Last Invoked Time (optional)	
LRS Time (optional)	
Last LRS Time (optional)	
Output Format (optional)	
FGDB	-
Output Spatial Reference WKID (optional)	
Practician (antion a)	
Precision (opcional)	3
LRM Translations (optional)	
1	v
OK Cancel Environments	Show Help >>

Create Roads and Highways Relocate Events Web Services

Create a Relocate Events web service for each External event registered in the <u>Register External Events with Roads and Highways</u> step. There are two main steps to creating a Relocate Events web service. First, you must run the geoprocess, and then share the results of that geoprocess as a web service. Both steps must be run for each registered External event.

The directions for running the geoprocess and creating the web service can be found on the Esri website at <a href="http://desktop.arcgis.com/en/arcmap/latest/extensions/roads-and-highways-server/deploying-relocate-event-tool-as-a-service.htm">http://desktop.arcgis.com/en/arcmap/latest/extensions/roads-and-highways-server/deploying-relocate-event-tool-as-a-service.htm</a>. Enter the network that corresponds to the base LRM in the AgileAssets system into the Network Layer. Select the Event Name for the external event associated with this iteration. Select CSV for the output format. And when specifying the Output Export File make sure to include a full name with a directory path (e.g. C:\Temp\Rel\_Events\_Pt).

Suggestion: when creating the web service and using the **Service Editor** dialog, under **Parameters** you may want to pick a Message Level of "Info" as this provides more meaningful error messages.

-	Relocate Events	
	Network Layer	<u>^</u>
	State_Milepoint	I 🖆
	Event Name	
	DEFAULT_EVENTS_LN	•
	Last Invoked Time (optional)	
	LRS Time (optional)	
	Last LR5 Time (optional)	
	Output Format (optional)	
	CSV	-
	Output Export File (optional)	
	c:\output\default_events_In.csv	
	Output Feature Class (optional)	
	Include Event Geometry (optional)	-
	OK Cancel Environments	Show Help >>

## Create LastEditDate Web Service

These steps create a LastEditDate web service, which allows the AgileAssets-Roads & Highways Interface to retrieve the latest edit date from the Lrs\_Edit\_Log table in Roads and Highways geodatabase. Follow the steps below to publish the web service and enter the URL into the Interface.

Note: To use this function, make sure the Lrs\_Edit\_Log table is registered as versioned in an enterprise geodatabase.

- 1. Create and register the SDE connection to the R&H geodatabase, or the folder location that contains the file geodatabase with the ArcGIS Server, if they are not already registered.
- 2. Download the **zip** file from the ftp site where the build artifacts are stored. Extract it to a folder.
- 3. Publish the service using either the command line option or ArcMap option, described as follows.

#### **Command Line Option:**

• Open a command line window from the folder that contains the script and use the **py** python script in command to publish the service. **publish.py**' s parameters are as follows:

-1	ArcGIS server admin address, e.g., https://arcgis.server.example.com/arcgis/admin/ Don't forget /arcgis
/admi	n/
-u	Admin username to access the server, e.g., siteadmin
-p	The password to the admin user
-s	If you are using a file geodatabase, this is the path leading to the file geodatabase, e.g., C:
\Data	\WORKSPACE\RH_GDB.gdb. If you are using an enterprise geodatabase, this is the path to the SDE connection
file,	e.g., C:\Data\WORKSPACE\WS_SDE.sde
-w	The workspace folder, e.g., C:\Data\WORKSPACE
-t	The exact table name for LRS Edit Log table. If you are using a file geodatabase, this is Lrs_Edit_Log.
If yo	u are using an enterprise geodatabase, this should include the database and schema prefix, e.g., RH_DEMO.
RH_DE	MO.Lrs_Edit_Log
-n	The name of the service (optional), e.g., LastEditDate. By default, it is Last_Edit_Date_Service.
-f	The ArcGIS Server folder where the service needs to be published, e.g., RH_Interface

For example:

Python publish.py -l https://arcgis.server.example.com/arcgis/admin/ -u siteadmin -p password -s C: \Data\WORKSPACE\WS\_SDE.sde -w C:\Data\WORKSPACE -t RH\_DEMO.RH\_DEMO.Lrs\_Edit\_Log -f RH\_Interface If the command line finishes without any error or warning messages, the service is successfully published.



#### ArcMap Option:

- 1. Open the folder in ArcMap, and open the tbx toolbox to display the LastEditScript
- 2. Double click the LastEditScript script under the tbx to open it.
- 3. For *inWorkspace* parameter:
  - If you are using a File Geodatabase, select the file geodatabase.
    - If you are using an enterprise geodatabase, select the SDE connection file with **default** version (or whatever version was used with the Export Network and Relocate Events web services).
- 4. For *editLogTableName* parameter:
  - If you are using a File Geodatabase, put Lrs\_Edit\_Log to this parameter.
  - If you are using an enterprise geodatabase, include the database and schema prefix, e.g., RH\_DEMO.Lrs\_Edit\_Log.

3	LatestEditScript		x
inWorkspace	7WYS_RIS71.gdb		^
editLogTableName Lrs_Edit_Log			
	OK Cancel Environments	Show Help >>	~
	OK Cancel Environments	Show Help >>	,

5. Click OK to run the tool, Follow this instruction and finish publishing the web service.

Note: For this GP service, make sure to select the Synchronous mode under the Parameter tab:

Connection: arcgis on dwarc	viu.agileassets.com (admin) Service	wimport 🚳 /	naa nesuit 💓 Prev	view 🗸 Analyze	Se Publish
General Capabilities Geoprocessing Parameters Pooling Processes LatestEditScript inWorkspace editLogTableName result Item Description	Parameters Cluster Choose the Cluster hosting the Execution Mode Synchronous Asynchronous (Recommended View results with a map so Properties Message Level: Maximum number of records ret Directories Jobs Directory: Virtual Jobs Directory: Virtual Jobs Directory: Virtual Output Directory: Virtual Output Directory: About geoprocessing service set	service et for long-running ser ervice urned by the server C: \arcgisserver\d [/rest/directories/i [/rest/directories/i ttings	default vices) None irectories\arcgisjobs arcgisjobs irectories\arcgisoutp arcgisoutput	1000	

Once the service is published, follow these steps to obtain the URL to the service:

- 1. Adjust the permission of the service in ArcGIS Server Manager and set it to **Public (Available to Everyone)**.
- 2. Save the URL. The URL is the webpage that has a **Execute Task** text at the bottom:



## Complete Interface Configuration on the AgileAssets System

On the standard AgileAssets system, you can return to the LRS Interface Setup window by following the steps below:

- 1. Click LRS/GIS
- 2. Select Roads & Highways Interface
- 3. Select LRS Interface Setup

To fill in the URLs that were left empty in an earlier step, follow the steps below:

System - Security	<ul> <li>Utilities -</li> </ul>	Settings +	Tools <del>+</del>	FDC <del>+</del>	LRS/GIS+	Interfaces +	Projec	:t Mgmt. +	Repo						≗ Pl	HIL+
System > LRS/GIS > Roads &	Highways Interface >	LRS Interface \$	ietup 🚖									E	Save Da	C Re	trieve	Data
Export Network Setup Actions															:=	8
Export Network URL						Time Zone	Syste	m ID	SRID	Execution Wait (s)	Exect	rtion Timeou	t (s) D	ownload Tin	neout	(s)
https://dwarcv5.agileassets.com:64	143/arcgis/rest/servic	es/AkDOT_Dem	o/ExportNetwor	WGPServ	er/Export%20Netw	o US/Alaska 🔻	Agile	Asset: 💌	3338	5			7200			1200
<< < 1 of 1 total rows >	>>															
* Relocate Events Setup - Even	t Categories Act	tions ¥													:=	53
Base Events Table Name	Relocate Events U	RL (Points)		Relocate	e Events URL (Lin	es)		Default E	vent Table	P Execution Wait (	s)	Execution Ti	meo	Download	Timeo	u
EVENTS_TO_BE_UPDATED	https://dwarcv5.agil	eassets.com:644	3/arcgis/rest/se	https://dv	warcv5.agileassets	.com:6443/arcgis/n	est/ser	2			5		7200			1200
SPECIAL_EVENTS	https://dwarcv5.agil	eassets.com:644	3/arcgis/rest/s	https://d	warcv5.agileassets	.com:6443/arcgis/r	est/ser				5		7200			1200
•																•
<< < 2 of 2 total rows >	>>															
* Relocate Events Setup - Mem	ber Tables Action	ns ¥													≣	22
Source Table																
SIGNAL_INVENTORY		*														
SUPPORT_INVENTORY		-														
<< < 2 of 2 total rows >	>>															

In the Export Network URL field on the top pane, enter the URL associated with the Export Network web service that you created. To find the URL to enter here, do the following:

- In a separate browser page, visit the ArcGIS Server Manager website for this instance.
- Inside ArcGIS Server Manager, go to Services > Manage Services.
- On this page, choose the folder where you placed the web service, and then click the **Export Network** web service (or whatever you named your service in the Create Roads and Highways Export Network Web Service step).
- Click **Capabilities** on the left-hand panel.
- Click the URL next to the phrase "Rest URL".
- Click the phrase Export Network under the heading
- Copy the URL from the address bar of the browser and paste it into the Export Network URL field of the LRS Interface Setup page.
  - If your ArcGIS server is configured to require authentication, you may need to add a proxy prefix to the start of the URL you just entered.



In the LastEditDate Service Link field on the top pane, enter the URL associated with the LastEditDate web service that you created. This is the URL created in the Create LastEditDate Web Service step.

• If your ArcGIS server is configured to require authentication, you may need to add a proxy prefix to the start of the URL you just entered.

In the **Relocate Events URL (Points)** field and in the **Relocate Events URL (Lines)** field on the middle pane, enter the URL associated with the Relocated web services that you created for each of these event categories. To find the URL to enter here, do the following for each event category:

- In a separate browser page, open the ArcGIS Server Manager website for this instance.
- Inside ArcGIS Server Manager, go to Services > Manage Services.
- On the new page, choose the folder where you placed the web service, and then click the Relocate Events web service you are working on.
- Click Capabilities on the left panel.
- Click the URL next to the phrase Rest URL.
- Click the phrase Relocate Events under the heading

Copy the URL from the address bar of the browser and paste it into the appropriate **Relocate Events URL** field of the LRS Interface Setup page.
 If your ArcGIS server is configured to require authentication, you may need to add a proxy prefix to the start of the URL you just entered.

## Install native FGDB libraries

One of the outputs of ESRI's Roads & Highways web services is an ESRI File GeoDatabase (FGDB). In order for our system to be able to read ESRI File GeoDatabases, native libraries must be installed.

For Linux-based servers, these libraries are named:

- so This library is written and provided by Numbered list
- ESRI, as part of the File GeoDatabase API, v. 1.4.
- so This library is written and provided by ESRI, as part of the File GeoDatabase API, v. 1.4.
- so This library is written and provided by AgileAssets and depends on the other libraries provided by ESRI.

For Windows-based servers, these libraries are named:

- FileGDBAPI.dll This library is written and provided by ESRI, as part of the File GeoDatabase API, v. 1.4.
- dll This library is written and provided by ESRI, as part of the File GeoDatabase API, v. 1.4.
- dll This library is written and provided by ESRI, as part of the File GeoDatabase API, v. 1.4.
- dll This library is written and provided by AgileAssets and depends on the other libraries provided by ESRI.

The implementation steps are as follows:

- 1. Obtain the AgileAssets libraries. The available AgileAssets libraries are listed above. Contact AgileAssets support and provide them with operating system details of your server.
- 2. Obtain the ESRI libraries. The Esri libraries are provided on Esri's download page.
  - Go to http://www.esri.com/apps/products/download/index.cfm?fuseaction=#File\_Geodatabase\_API\_1.4
  - Download the appropriate package for the required operating system.
  - Unpack the package.
  - Find the required libraries in the FileGDB\_API/lib directory.
- 3. Install the libraries. Create a directory on the application server and put all required libraries (from both Esri and AgileAssets) in that
  - directory. Make note of the directory name. For the examples below we used /usr/local/tomcat/geo\_libs.
- 4. Create a script that lets the application server know the whereabouts of these libraries. Replace "/usr/local/tomcat/geo\_libs" in the directions below with the location of your libraries as appropriate.
  - For Linux:
    - If a file named setenv.sh does not exist in the Tomcat bin directory, then create it and make it executable.
    - For Linux, add ONE of these lines to setenv.sh:
      - For versions of Java below 7 and if LD\_LIBRARY\_PATH is already set on the system:
    - LD\_LIBRARY\_PATH=\$LD\_LIBRARY\_PATH:/usr/local/tomcat/geo\_libs
    - For versions of Java below 7 and if LD\_LIBRARY\_PATH is not already set on the system:
       LD\_LIBRARY\_PATH=/usr/local/tomcat/geo\_libs
    - For Java 7 and above, the LD\_LIBRARY\_PATH needs to be exported and set this way:
    - export LD\_LIBRARY\_PATH="/usr/local/tomcat/geo\_libs"
    - export LD\_LIBRARY\_PATH=/usr/local/lib:\${LD\_LIBRARY\_PATH}
    - JAVA\_OPTS="Djava.library.path=/usr/local/tomcat/geo\_libs"
  - For Windows:
    - If a file named setenv.bat does not exist in the Tomcat bin directory, then create it and make it executable.
    - Add this line to setenv.bat:
      - Set PATH = %PATH%;\usr\local\tomcat\geo\_libs
- 5. Restart Tomcat.

#### Make at least one event table temporal

Because Roads and Highways keeps track of the dates associated with each edit the AgileAssets side of the interface needs to have fields to store this data. Those fields are created when at least one linearly-referenced table is set to **Keep Change History**.

System > U	niities > Database / System mns Indexes Java Ti	n Management > Tables	û							🖹 Save Data C R	etrieve
Actions ¥										:=	25
um. of Atta	Max. Image. Height	Max. Image. Width	Table Type	XY Coor. Ref. Sys.	Comments	Attachment	Date	User U	Keep change history?	Supports Staged Editi	ng 4
			General				02/06/20	SAM	•		
			General		Equipment Day Cards ?Numbe		03/06/20	SAM			
			General		Labor Day Cards - Details like		04/28/20	ERICK	•		
			General	-	Stores all Locations/Assets line		05/16/20	PHIL	·		
			General	-			09/13/20	ERICK	Delete		
			General	-	Stores all Work Requests in the		10/27/20	CHARLES	Make Window		
			General	-			03/04/20	ABDUS	Apply Changes Refresh From D	atabase	
			General				07/21/20	HIMANSH	Import Table Da	ita	
			General	-			07/21/20	HIMANSH	Eind Sort		
			General	-			10/20/20	HIMANSH	Filter By This Va	alue	
			General	-			05/10/20	TRAVIS	Work With Attac	hments	
			General	-			04/30/20	SAM	Export Data		
						1		1	Clipboard Wind	low Andows	
< 1324	of 1368 total rows > >>								Show Changes	indows	

To make a table temporal, follow the steps below:

- 1. Go to System > Utilities > Database/System Management > Tables (or wherever this window is on your implementation.
- Find a linearly-referenced table (one that has route and measures) and select its row in the table.
   Scroll to the far right of the window and place a check mark in the Keep Change History
- 4. Right-click the row to bring up the context menu and select Apply Changes.
- 5. A dialog may appear asking you to give a beginning birth date for your existing records in this table. By default it is 1/1/1900. Give it a date of your choosing and click OK.
- 6. Next a dialog will appear asking if it is OK to process the script needed to make the table temporal. Click OK. This process will likely take several minutes depending on the number of records in the table.
- 7. After the script completes click the Save Data button and this task is complete.

# Configure Excluded Tables and Interface Type

An AgileAssets support person will work with you to make sure that the proper settings are made for tables to be excluded from the interface job and that your system is set to use the Roads & Highways Interface type.